

XYR 5000 Wireless Dual Discrete Input

Model Selection Guide with Price Data

Model Selection Guide
34-XY-16-12 Issue 2

Honeywell Proprietary

Instructions

- Select the desired key number.

Key Number	-	II (Approvals)
- - - -		- -

List Price equals the sum of all prices for all selections made.

KEY NUMBER	Availability	U.S.\$
Description	Selection	
Wireless Dual Discrete Input Transmitter with Omni Directional Antenna	WW591 ↓	
Wireless Dual Discrete Input Transmitter with Integrated Yagi Antenna	WW592 ↓	

TABLE I - CERTIFICATION OPTIONS

Certificate	Approval Type	Location or Classification			
Combined FM & CSA	Intrinsically Safe	CL I, II, III, Div 1, Gp A,B,C,D,E,F,G T4; CL I, Zone 0, AEx ia IIC T4; Enclosure Type 4	AG	•	b
	Nonincendive	Class I, Div 2, Groups A,B,C,D; Suitable for CL II, III, Div 2, Gp F,G, T4; CL I, Zone 2, AEx nA IIC T4; Enclosure Type 4			
	Intrinsically Safe	CL I, II, III, Div 1, Gp A,B,C,D,E,F,G T4; CL I, Zone 0, Ex ia IIC T4; Enclosure Type 4			
	Nonincendive	Class I, Div 2, Groups A,B,C,D; Suitable for CL II, III, Div 2, Gp F,G, T4; CL I, Zone 2, Ex n IIC T4; Enclosure Type 4			
	ATEX*	Multiple Marking** Int. Safe, Zone 0/1, or Non-Sparking, Zone 2			

* See ATEX installation requirements in the Operator's Manual.
 ** The user must determine the type of protection required for installation of the equipment. The user shall then check the box [√] adjacent to the type of protection used on the equipment certification label. Once a type of protection has been checked on the label, the equipment shall not then be reinstalled using any of the other certification type.

RESTRICTIONS

Restriction Letter	Available Only With		Not Available With	
	Table	Selection	Table	Selection
b		Mutually exclusive - select one		